5. Troubleshooting

Problem	Check	Remedy
¡ Motor does not run when turned on	¡ Check that the plug is securely inserted into outlet ¡ Check that the carbon-brush is not severely worn ¡ Check that the hook in the carbon-brush in separated ¡ Check that the power switch is truned on ¡ Check that the contact at the cord-reel area is ok	¡ Plug in firmly ¡ Push it completely into the brush holder or replace it ¡ Replace if motor does not run when turned on ¡ Replace it if broken
¡ Slide control does not adjust	¡ Check that the slide switch is not broken ¡ Check that the triac is not shorted ¡ Check that the base plate is not broken	¡ Replace ¡ Replace ¡ Replace
¡ Cord does not rewind fully	¡ Check that the cord is not twisted or wound unevenly ¡ Check that the spring is not weak or broken	¡ Pull the cord ou 2~3m and push down the rewinding button ¡ Replace ¡ Replace the power cord if it does not fully rewind
¡ Cord rewinds by itself	¡ Check that the lever is not broken ¡ Check that the rubber is not separated	¡ Replace ¡ Reassemble the rubber
¡ Suction power is week	¡ See if the floor nozzle or the hose is clogged with a large object ¡ Check that the cover is attached firmly to the body ¡ Check that the hose is firmly inserted	¡ Remove the object ¡ Attach the cover properly ¡ Insert the hose firmly
¡ The needle of the dust indicator is in the red position.	¡ Check that the floor nozzle or the hose is not clogged with a large object ¡ Check that the spring of the dust indicator is ok ¡ Check that the filter sponge is clean	¡ Remove the object ¡ Replace the spring ¡ Clean the sponge